




COMMERCIAL AUTOMATIC WASHER

MODELS:

MAT24PRAWW0 (White)


TOP AND CABINET PARTS



TOP AND CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	W10482836	Latch, Lid Lock Assembly	31	54583	Hinge, Lid
	W11647814	Installation Instructions	15	W10588613	Screw	32	W10461181	Bushing-Top, Screw
	W11691910	Tech Sheet	16	W11417173	Panel, Rear	33	90406	Nut, Cage
	W10860796	Instructions, Installation (Card Reader)	17	W10845574	Cabinet (White)	34	W11129581	Bracket, Front Top
2	W11349835	Top, (White)	18	W11634773	Brace, Cabinet Top - Front (Hooks Removed)	35	3353994	Bolt
3	W11349836	Assembly, Lid and Bumper (White)	19	W11089573	Brace, Cabinet Top - Rear	36	W10486616	Screw
4	W11241723	Bumper, Lid	20	W10660565	Screw	37	356674	Cone, Wedge
5	9740848	Screw	21	W10461182	Lock, Top	38	W11610868	Bracket, Base
6	91770	Hinge, Lid	22	W10245373	Foot, Leveling	39	W11552072	Panel, Front (White)
7	W10119872	Screw	23	W10461176	Hinge, Top	40	W10866521	Bracket, Front Panel
8	W10240513	Strike, Lid Lock (White)	24	W10142728	Screw	41	8283273	Damper, Brace
9	W10273971	Screw	25	W10461180	Cover, Harness	42	W10862638	Lock, Top Front
10	W10348582	Clamp, Hose	26	3400076	Screw	43	W11096159	Damper, Sound
11	W10392041	Bezel, Lid Lock (White)	27	W11203364	Hose, Outer Drain Assembly	44	W10866523	Rivet
12	21258	Bearing, Lid Hinge	28	W10280024	U-Bend, Drain Hose	45	3359452	Nut, Hex
13	90016	Clip, Harness	29	356138	Clamp, Hose	46	356907	Rivet, Plastic
			30	W10339879	Tie, Cable	47	W10567155	Screw
						48	W10161707	Top, Foam Seal


CONTROLS AND WATER INLET PARTS



CONTROLS AND WATER INLET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11124005	Console	12	W11032871	Relay	23	W11512927	Jumper, Switch Service/Vault
2	W10131839	Transformer	13	W10843663	Inlet Assembly, Water	24	W10137770	Retainer, Card Reader Cover
3	W11455494	Control Unit Assembly, Machine & Motor	14	W10843398	Harness, Valve	25	W10137769	Cover, Card Reader
4	W11425708	Panel, Console Rear Cover	15	W10133514	Standoff, Circuit Board	26	3400618	Screw
5	W10660565	Screw	16	W10131123	Nut, "U"	27	W10131115	Bezel
6	W10131119	Screw	17	W10137322	Screw	28	W11512926	Card Reader, Harness
7	W10916258	Cord, Power	18	W10821635	Fascia	29	W11736367	Kit, Card Reader Conversion
8	3400076	Screw	19	W10139046	Nut			
9	W11565137	Cover, Display	20	W11407433	Bracket, Control			
10	W11456057	User Interface	21	W10242307	Washer, Hose			
11	W10843665	Harness, Upper	22	W10852720	Inlet, Cold Water			
				W10852721	Inlet, Hot Water			


BASKET AND TUB PARTS



BASKET AND TUB PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10131111	Cap, Agitator	9	21366	Nut, Spanner	15	W10238320	Tub
2	W10003790	Screw and Washer	10	W10198148	Block, Basket Drive	16	W10843660	Harness, Lower (Includes Pressure Hose)
3	3949550	Washer	11	W10215093	Filter, Drain Pump	17	W10531633	Hose, Pressure Switch
4	W10131112	Agitator	12	8533928	Screw	18	W10005430	Clamp, Cable
5	W10755559	Rubber Washer, Impeller	13	W10839119	Strap, Snubber	19	8533943	Screw
6	W10424289	Adapter, Balance Ring	14	W10821954	Damper Assembly, Tub Suspension (Set Of 4-Includes Suspension Bushings and Suspension Balls)			
7	W10461196	Ring, Tub						
8	W10389330	Basket Assembly						

GEARCASE, MOTOR AND PUMP PARTS



GEARCASE, MOTOR AND PUMP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10276397	Pump Assembly, Drain	6	W10249633	Screw	12	W11625774	Capacitor, Motor Run
2	W10004910	Screw	7	W10850134	Motor, Drive	13	W10427633	Shield, Pulley Cover
3	W10763078	Hose, Inner Drain Assembly	8	W10094780	Screw	14	357640	Screw
4	8317496	Clamp, Hose	9	W11495180	Belt, Drive	15	W10721967	Splutch Kit (60Hz)
5	W11261592	Assembly, Gearcase	10	W11112160	Actuator, Shift			
			11	9741052	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	Paint, Touch-up (White 1/2 oz)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350938	Paint, Spray (Gray Primer 12 oz)
	350930	Paint, Spray (White 12 oz)
		PAINT, BULK (1 qt.)
	799344	Paint, Bulk (White Uncut 1 qt)
		SEALER
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)
		ACCESSORY PARTS
	W10135699	Affresh® Washer Cleaner
	8212526	Washer, Drip Tray
	W10576550	Main Top Rear Support
		WATER SYSTEM PARTS
	285834	Siphon Break Kit
	285835	Connector Assembly
	285863	4 Ft. Drain Hose w/Clamp
	3363920	Adapter, Standpipe 2 in. Diameter to 1 in. Diameter
	76314	Hose, Inlet (6' Hose With Elbow)